

# S.E.R.E.M.E EXPANDER LEGER EN COMPOSITE NON GUIDE



Ø Expandeur mm	Ø ARMATURE mm	Masse Kg	Premier mode élastique Hz	Mode de pompage Hz	Amortissement
1000	445	≤ 100	≥ 950 Hz	≥ 950 Hz	Entre 1,5 % et 4,5 % suivant les modes
1200	480	≤ 120	≥ 570 Hz	≥ 590 Hz	
1200 (carré)	480	≤ 140	≥ 300 Hz	≥ 610 Hz	
1500	450	≤ 200	≥ 380 Hz	≥ 475 Hz	
1500	650	≤ 230	≥ 710 Hz	≥ 710 Hz	
1500	450	≤ 165	≥ 380 Hz	≥ 380 Hz	
2000	610	≤ 380	≥ 380 Hz	≥ 380 Hz	
3400	700	≤ 1000	≥ 140 Hz	≥ 140 Hz	



**S.E.R.E.M.E.**

ZI La Marinière – 31, rue Gutenberg  
B P 51 – 91072 BONDOUFLE Cedex – France

☎ 00 33 1 60 86 42 36 - 📠 00 33 1 60 86 52 55

sereme@sereme.com